

NewLife™

LIQUID POT HOLE FILLER

ILLUSTRATED APPLICATION INSTRUCTIONS



Step One:

Use a blower to remove all loose debris from the pot hole.



Step Two:

If the pot hole is wet, dry with a torch prior to filling.



Step Three:

After mixing Part A and Part B together, pour product into prepared pot hole.



Step Four

Once poured, the pot hole filler will immediately begin to set. Using a trowel or a 1"x3", level the product as needed.



Step Five:

Pot hole completed. Allow 20 minutes set time before opening to traffic.



Step Six:

Ready for traffic!